

CONTENTS

preface

USING THIS GUIDE

Symbols	iv
Technician Notes	v
Serial Number	v
Laser Safety	v
CDRH Regulations	v
Battery Notice	vi
Locating Additional Information	vii

chapter 1

PRODUCT DESCRIPTION

1.1 Computer Features and Models	1-1
1.1.1 Features	1-2
1.1.2 Models	1-3
1.1.3 Software Fulfillment	1-3
1.2 Computer Options	1-3
1.2.1 Convenience Base II	1-3
1.2.2 System Memory Options	1-3
1.2.3 External Battery Charger	1-4
1.2.4 External Keyboards and Pointing Devices	1-4
1.2.5 External Monitors	1-4
1.3 External Computer Components	1-5
1.3.1 Left Side Components	1-5
1.3.2 Front Components	1-6
1.3.3 Top Components	1-7
1.3.4 Right Side Components	1-8
1.3.5 Rear Components	1-9
1.3.6 Computer Bottom Components	1-10
1.3.7 M35EU Bottom Components	1-11
1.3.8 Status Panel Lights	1-12
1.4 Design Overview	1-13
1.4.1 System Unit	1-13
1.4.2 Internal Boards	1-13
1.4.7 Video system	1-14

chapter 2

TROUBLESHOOTING

2.1 Preliminary Steps	2-2
2.2 Clearing Passwords	2-3
2.3 Power-On Self-Test (POST)	2-3
2.4 POST Error Messages	2-4

2.5 Compaq Utilities	2-7
2.5.1 Computer Setup	2-7
2.5.2 Computer Checkup (TEST)	2-9
2.5.3 Running View System Information (INSPECT)	2-16
2.5.4 Running Compaq Diagnostics	2-16
2.5.5 Boot Sequencing	2-16
2.5.6 Factory Default Settings	2-17
2.6 Troubleshooting Without Diagnostics	2-18
2.6.1 Before Replacing Parts	2-18

chapter 3

ILLUSTRATED PARTS CATALOG

3.1 System Unit.....	3-2
3.2 Mass Storage Devices	3-4
3.3 Cables and Power Cords	3-5
3.4 Standard and Optional Boards	3-6
3.5 Options	3-7
3.6 Miscellaneous Parts	3-8
3.7 Documentation	3-10

chapter 4

REMOVAL AND REPLACEMENT PRELIMINARIES

4.1 Tools Required.....	4-1
4.2 Service Considerations.....	4-1
4.2.1 Plastic Parts.....	4-1
4.2.2 Cables and Connectors.....	4-2
4.3 Preventing Damage to Removable Drives	4-2
4.4 Preventing Electrostatic Damage	4-3
4.4.1 Packaging and Transporting Precautions.....	4-3
4.4.2 Workstation Precautions	4-4
4.4.3 Grounding Equipment and Methods.....	4-5
4.4.4 Electrostatic Voltage Levels and Protective Materials	4-6

chapter 5

REMOVAL AND REPLACEMENT PROCEDURES

5.1 Serial Number	5-1
5.2 Disassembly Sequence.....	5-2
5.3 Preparing the Computer for Disassembly	5-3
5.3.1 Disconnecting the AC Power.....	5-3
5.3.2 Removing the PCMCIA Card.....	5-6
5.3.3 Removing the Battery Pack	5-7
5.4 Memory Board	5-8
5.4.1 Removing the Memory Module.....	5-9
5.4.2 Installing the Memory Module	5-10

5.5 Hard Drive.....	5-11
5.5.1 Removing the Hard Drive Cover	5-11
5.5.2 Removing the Nickel Cadmium Auxiliary Battery	5-12
5.5.3 Removing the Lithium Real Time Clock Battery	5-13
5.5.4 Removing the Hard Drive.....	5-14
5.6 Keyboard.....	5-15
5.7 Display Assembly	5-17
5.7.1 Removing the Display Hinge Covers	5-17
5.7.2 Removing the Switch Cover/Status Panel	5-18
5.7.3 Removing the Display Assembly	5-20
5.8 Top Cover Assembly.....	5-22
5.8.1 Removing the DC-DC Converter.....	5-24
5.8.2 Removing the System Board	5-25
5.8.3 Removing the Fan.....	5-26
5.9 Removing a MultiBay Device.....	5-27

chapter 6

SPECIFICATIONS

6.1 Computer.....	6-2
6.2 Display	6-3
6.3 Hard Drives	6-4
6.4 Diskette Drive	6-5
6.5 Optical Disc Drives	6-6
6.6 System Interrupts	6-8
6.7 System DMA.....	6-8
6.8 System I/O Address	6-9
6.9 System Memory Map.....	6-11

appendix A

CONNECTORS	A-1
-------------------------	-----

Appendix B

POWER CORD SET REQUIREMENTS

B.1 3-Conductor Power Cord Set.....	B-1
B.1.1 General Requirements	B-1
B.1.2 Country-Specific Requirements	B-2
B.1.3 Notes:	B-2

Appendix C

CONVENIENCE BASES

C.1 Models and Features.....	C-1
C.2 Convenience Base Features	C-2
C.3 Convenience Base II Components	C-3
C.3.1 Front and Right Side Components	C-3
C.3.2 Rear Components	C-4

INDEX	I-1
--------------------	-----

